



45/0 LAV Fiber Package Adapter

(C02-1002-030)

Instruments: MiniScan

Purpose: This option provides a special nose cone assembly and three removable adapters for measuring 6-inch (152-mm), 10-inch (254-mm), and 12-inch (305-mm) cylindrical fiber or yarn package diameters.



Sample Measurement: To use the assembly, snap the appropriate port adapter onto the nose cone of the MiniScan EZ. Position the port adapter over the cylindrical fiber or yarn package and proceed with measurements. Take care to position the MiniScan EZ so that it will not move during readings. Averaging is recommended when measuring fibers or yarns with large diameters.

